













EN Assembly scheme | DE Aufbauanleitung | FR Schéma d'assemblage

 00:20	 x2	      
---	---	--



Desk with fixed pedestal, left/ right
Schreibtisch mit Festschrank, rechts/links
Bureau avec caisson fixe, droite/gauche






a - x1



b - x1



c - x1




d - x1



f - x1




g - x1



h - x1



i - x1




j - x1



k - x1*

*Optional
*Optional
*Optionnel



1 x14

M6x16
M42C0255/
M42C0335



2 x4

M8x35
M42P0013/
M42P0015



3 x2

M59C0243



4 x1

M42Z0070



5 x1

M4x10
M42C0061



6 x1

M6
M42D0071



7 x2

∅8x20
M42H0025




8 x4

∅6,3x13
M42C0030



9 x4


M45A20*




10 x4

M45C0140


1a



1b




2




M8x35
M42P0013/
M42P0015


3b




4b



5b








6b




Ø6,3x13
M42C0030

8 x4

7



8b





M6x16
M42C0255/
M42C0335

1 x6



90°

Check the alignment
Überprüfen Sie die Ausrichtung
Vérifier l'alignement






9








10




11







12




13




14




15b




1.




2.




16b





1.




2.




17



*1



*2



JourTym e.K.

Telefon: +49(0)30 / 460 681 71

E-Mail: info@bueromoebel-guenstig.de

Web: www.bueromoebel-guenstig.de